



# **BIG FOOT**

## **Large Diameter Foot Attachment**

### **Part No. BF-1**



### **Big Foot Installation:**

1. Loosen the hex screw on the Big Foot attachment
2. Slide the Big Foot attachment onto the lower barrel of the gauge
3. Position the Big Foot attachment so that the ½" gauge foot protrudes approximately .002 - .003" past the Big Foot attachment (the Big Foot should be almost flush with the gauge foot)
4. Tighten the hex screw on the Big Foot attachment

*Note: Increasing foot diameter can affect durometer readings.*

← **Big Foot Attachment**

If you have any questions or comments regarding the use of this or any Rex product, please call toll free at 1-800-927-3982.



## **REX GAUGE COMPANY, INC.**

A DIVISION OF SCHULTES PRECISION MANUFACTURING

1250 Busch Parkway Buffalo Grove, IL 60089

**800/927-3982** LOCAL: 847/465-9009 FAX: 847/465-9229

[www.durometer.com](http://www.durometer.com)